

# Кабельное напольное покрытие

## Информация о продукте

Имя	Кабельное напольное покрытие
Цвет	Красный, оранжевый, черный, синий, камуфляжный цвет и т. д.
Длина	1-50 м, настройка
Ширина	50-250 мм, настройка
Материал	Нейлон полиэстер, на заказ
Упаковка	Полиэтиленовый пакет

Покрывтие кабельного пола — это аккуратный и простой способ удержать кабели на месте и свести к минимуму риск спотыкания о кабели или поражения электрическим током. Защитную пленку для напольного кабеля можно разрезать ножницами в соответствии с вашими потребностями, многократно открывать и закрывать, не оставляя следов клея, легко снимать и чистить, можно использовать многократно. Он подходит для закрытых и офисных ковров, хорошо работает на полу под столами или по периметру пола.

## PRODUCT DESCRIPTION



# SECOND GENERATION

## FLOOR CABLE COVER

Wires management orderly  
tidy and not messy



# Do you feel upset seeing the messy wires?

It will be ease and comfortable after using the wire cover



## Before use

it is disorganized, wires are easy to trip and wear



## After use

it is neat and orderly, anti-stumbling, it protects the wires from fraying



**The second generation wire cable sleeve cover has more complete functions and better use effect**

## **Hook & loop type**

### **Cover area**

High density wear resistant material

### **Waterproof coating**

Effectively block water leakage

### **Hook**

Flat, high toughness and strong bite force

### **Loop**

Fine nylon fabric tear-resistant and durable

### **Glue**

Strong adhesion

**NO NEED TO DRILL  
SIMPLE TO USE**



**We can customize carpet cover of different widths and sizes in small quantities to cater to different scenes**



**5cm**



**8cm**



**10cm**



**11cm**



**13cm**



**15cm**



**Can be cut according to needs**




# **WATERPROOF WITHOUT LEAKAGE**




**Strong drainage effect, no dripping**

**The new hook of the second generation is thinner after fitting, which is not easy to trip**



**The height after bonding is about 2mm**



**The height after bonding is about 4mm**





1 Peel the backing paper off the loop tape.



2 Attach to the location where the wires need to be placed, and press the tape to stick firmly.



3 Open the cable cover by tearing off one of the hook side and put the wires inside.



4 After arranging the wires neatly, close the covers by attaching hook to loop.



# **Storage & Organization**

## **Applicable to a variety of scenarios**



**Home**



**Control room**



**Engineering**



**Office**